

## ESF5542LOW



#### Natural drying with fresh air

×

Our 300 AirDry Dishwasher finishes each cycle with a breath of fresh air, performing 3x better than closed-door systems. The door opens automatically during the drying phase using fresh air to get plates and cutlery completely dry.

### **Product Benefits & Features**

**Clean dishes always ready when you need them** Need clean dishes in a hurry? That's no problem thanks to the Time Manager feature on this dishwasher, which makes it possible to reduce the cycle time by half.



×

Run your dishwasher whenever it suits you This dishwasher gets to work when you want it to. With its Delay Start function, you can load it when you want to and program it to start at the time that suits your schedule. You can delay the start by up to 24 hours.

×

x

# Spotless and sparkling, in every cycle

Our AutoFlex programme with smart sensor adjusts the consumption of each dishwashing cycle to the size and cleanliness of every load. Using only what is needed so that all dishes emerge spotless. No wasted water, energy or time. Just efficiently sparkling, every time. Guarantee dry dishes with automatic AirDry technology

AirDry technology uses natural airflow to finish its drying cycle. It automatically opens the door by 10cm in the last part of the cycle until you're ready to unload. A natural way to get maximum drying performance while effectively reducing your energy costs.

- Installation: Freestanding
- Indications for Delay start 1h-24h, Drying phase, Program selected, Rinse
- aid, Salt, TimeManager, Washing phase, XtraDry
- Noise level: only 44 (dB(A) re 1 pW) (2010/30/EC)
- Indications for salt and rinse aid
- Lower basket with 2 foldable plate racks, Plastic coloured handle
- Water sensor detects the level of dirt and adjusts water consumption
- Glass protection program
  - Energy efficiency (2010/30/EC): A++
  - Appliance HxWxD (mm): 850 x 600 x 625
  - Inverter motor
  - Delay start option from 1 to 24 hours
    Electrolux, Erec.standing, Full, Width Dishursher, EREC.4014
  - Electrolux Free-standing Full\_Width Dishwasher ESF5542LOW
    Waterstop System
  - Dishwashar
- Dishwasher
- Noise level: only 44 dB
- Water and energy consumption: 9.9 I, 0.92 kWh for program Eco 50
- Water and energy consumption: 9.9 l, 0.92 kWh for program Eco 50
- Text/symbol panel
- Dishwasher programmes: AutoFlex 45°-70°, Eco 50°, GlassCare 45°, Intensive 70°, QuickPlus 60°, Rinse & Hold
- Thermo Efficient System
- SENSORCONTROL dishwasher



## ESF5542LOW

### **Product Specification**

White
А
А
А
202.4
Eco 50
13
White
White
10
1950
220-240
PL
850x600x625
45.5
Free-standing

