



#### The fastest way to flavour

Get your hob hotter, faster with the 300 Induction Hob. With no gas to ignite or coils to pre-heat, cooking zones reaches high temperatures quickly, so water boils faster than ever. And it responds instantly when you lower the heat, giving you total control.

### Product Benefits & Features

#### Easy, fast and safe - Induction

Induction technology means that heat is delivered quickly and to precisely the right spot, meaning the surrounding areas remain cool and safe. It also reacts instantly to temperature changes. And the smooth surface makes it easy to clean.

- Hob type: Induction
- Hob with bevelled frame
- Controls position: Front Middle
- Illuminated controls
- Induction zones with power booster function
- Pot detection
- Left front zone: No, 0W/0mm
- Left rear zone: Induction, 2300/3200W/210mm
- Middle front zone: No, 0W/0mm
- Middle rear zone: Induction, 2300/3200W/210mm
- Right front zone: No, 0W/0mm
- Right rear zone: Induction, 2300/3200W/210mm
- Automatic fast heating up
- Key-lock function
- Child safety lock function
- Automatic safety switch off
- Acoustic signal with switch off option
- CountUp Timer
- EcoTimer™
- Timer function
- CleverHeat™ function
- Easy installation thanks to snap-in system
- Main colour: Black

#### Hob2Hood® for pure convenience

The Hob2Hood® function wirelessly connects your hob to your hood. Start cooking, and the hood will automatically adjust the settings, providing the best extraction based on the power selected on the hob. It does the hard work for you.



#### Intense heat, in an instant with PowerBoost

Activate the PowerBoost function for an instant burst of heat during cooking. It's ideal for getting dishes ready faster. You can boil water quicker than ever before, and get pans ready for searing when you need them.

#### Effortlessly time every step of your recipe

The adjustable timer helps you to follow the cooking process effortlessly. It can be set up to one hour, and gives you an accurate reminder of your cooking time. It turns the selected cooking zone off when the time has elapsed and doubles as a minute minder when you're not using the hob.

#### Lock your cooking settings

The key lock feature on our hob means your cooking settings will stay as they are, even if the control panel is accidentally touched by anyone – even children. This also means you can wipe up any spills without affecting the cooking process.

Product Specification

Product Installation	Built_In	Built in height mm	44
Product Typology	Electric_Hob	Width cutting	880
Product Classification	Exploration	Depth cutting	380
Installation	Independent	Radius cutting	5
Size	90	Fastening	Snap in System
Hob type	Induction Full	Gas original	No
Design family	Electrolux 100	Gas replacement 2	No
Main colour	Black	Gas replacement 3	No
Control Panel material	Glass	Gas category	NOne
Frame type	Bevelled 1 Side	Frequency	50-60
Frame material	No		
Knobs colour	No		
Top Control Place	Front Middle		
Type of controls	Pelican		
Control function	3 step residual heat, Acoustic signal, Automatic heating-up, Booster, Child-lock, Count up timer, Eco timer, Key-lock function, Minute minder, Pause, Sound off, Timer		
Other comments controls	Power - Management		
Other comments design	windmill		
Other comments categorisation	ref. 949 596 022, MID RANGE, WINDMILL Design		
Width mm	910		
Depth mm	410		

